## **SIEMENS**

Data sheet 3RQ3052-1SM30



Output coupler Optocoupler 1 NO, Transistor, 24 V DC Output max. 30 V DC, 2 A short circuit-proof screw terminal Overall width 6.2 mm Thermal current 2A  $\,$ 

product brand name	SIRIUS
product category	SIRIUS 3RQ3 coupling relays in slim design
product designation	Coupling relays with semiconductor output (not plug-in)
design of the product	Output coupling link
product type designation	3RQ3
General technical data	
display version LED	Yes
product feature protective coating on printed-circuit board	No
product component	
<ul> <li>relay output</li> </ul>	No
semi-conductor output	Yes
consumed active power	0.3 W
insulation voltage for overvoltage category III according to IEC 60664 with degree of pollution 3 rated value	50 V
surge voltage resistance rated value	2.5 kV
protection class IP	IP20
flammability class of enclosure material	UL94 V-0
shock resistance	
according to IEC 60068-2-27	sinusoidal half-wave 15g / 11 ms
vibration resistance	
according to IEC 60068-2-6	6 150 Hz: 2 g
switching frequency	100 Hz
thermal current	2 A
reference code according to IEC 81346-2	K
Substance Prohibitance (Date)	03/25/2015
Control circuit/ Control	
control supply voltage at DC	
rated value	11 30 V
operating range factor control supply voltage rated value at DC	
• initial value	1
full-scale value	1
minimum switching voltage when switching on	11 V
maximum switching voltage when switching off	5 V
ON-delay time	
at DC maximum	0.2 ms
OFF-delay time	0.3 ms
product component plug-in socket	No
Auxiliary circuit	
type of switching contact	NO contact
number of NO contacts for auxiliary contacts	1

Main circuit	
type of voltage	DC
Inputs/ Outputs	
property of the output short-circuit proof	Yes
switching voltage of the semiconductor output at DC	10 30 V
ampacity of the semiconductor output at DC	5 mA 2 A
Electromagnetic compatibility	
EMC emitted interference according to IEC 60947-1	ambience A (industrial sector)
EMC immunity according to IEC 60947-1	corresponds to degree of severity 3
conducted interference	contrapondo la dagresa el carrente y
due to burst according to IEC 61000-4-4	2 kV
due to conductor-earth surge according to IEC 61000-4-5	2 kV
due to conductor-conductor surge according to IEC	1 kV
61000-4-5	
field-based interference according to IEC 61000-4-3	10 V/m
electrostatic discharge according to IEC 61000-4-2	6 kV contact discharge / 8 kV air discharge
Display	
display version as status display by LED	LED green
Connections/ Terminals	
product function removable terminal	No
type of electrical connection for auxiliary and control circuit	screw-type terminals
wire length	
at DC maximum	1 000 m
type of connectable conductor cross-sections	
• solid	1x (0.25 2.5 mm²)
<ul> <li>finely stranded with core end processing</li> </ul>	1x (0.25 1.5 mm²)
for AWG cables solid	1 x (20 14)
connectable conductor cross-section	
• solid	0.25 2.5 mm²
finely stranded with core end processing	0.25 1.5 mm²
AWG number as coded connectable conductor cross section	
• solid	20 14
tightening torque with screw-type terminals	20 14 0.5 0.6 N·m
tightening torque with screw-type terminals Installation/ mounting/ dimensions	
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position	0.5 0.6 N·m any
tightening torque with screw-type terminals Installation/ mounting/ dimensions mounting position fastening method	0.5 0.6 N·m  any snap-on mounting
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position  fastening method height	0.5 0.6 N·m  any snap-on mounting 93 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth	0.5 0.6 N·m  any snap-on mounting 93 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position  fastening method height width depth required spacing	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth required spacing • with side-by-side mounting	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm 72.5 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth required spacing  • with side-by-side mounting — forwards	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm 72.5 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards	any snap-on mounting 93 mm 6.2 mm 72.5 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards	any snap-on mounting 93 mm 6.2 mm 72.5 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position  fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side	any snap-on mounting 93 mm 6.2 mm 72.5 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — backwards — upwards — downwards — at the side • for grounded parts — forwards	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — backwards — a the side	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position  fastening method height width depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — upwards — a the side  • for grounded parts — forwards — backwards — upwards	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — at the side — upwards — at the side — downwards — at the side — downwards	0.5 0.6 N·m  any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for grounded parts — forwards — backwards — upwards — at the side — downwards — at the side — downwards  • for live parts	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for grounded parts — forwards — at the side — downwards — at the side — downwards • for live parts — forwards	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position  fastening method height width  depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side • for grounded parts — forwards — backwards — upwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position  fastening method height width  depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side — downwards  • for live parts — forwards — backwards — backwards — backwards — upwards	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side — downwards  • for live parts — forwards — backwards — backwards — upwards — torwards — backwards — upwards — backwards — backwards — backwards — upwards — backwards — upwards — downwards	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • with side-by-side mounting  — forwards  — backwards  — upwards  — downwards  — at the side  • for grounded parts  — forwards  — backwards  — upwards  — at the side  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — backwards  — upwards  — downwards  — downwards  — at the side  — downwards  — at the side  — downwards  — at the side	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
tightening torque with screw-type terminals  Installation/ mounting/ dimensions  mounting position fastening method height width depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side  • for grounded parts — forwards — backwards — upwards — at the side — downwards  • for live parts — forwards — backwards — backwards — upwards — torwards — backwards — upwards — backwards — backwards — backwards — upwards — backwards — upwards — downwards	any snap-on mounting 93 mm 6.2 mm 72.5 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm



ambient temperature

during operation

• during storage

during transport

-25 ... +60 °C -40 ... +85 °C

10 ... 95 %

-40 ... +85 °C

relative humidity during operation

Certificates/ approvals

**General Product Approval** 

**EMC** 

**Declaration of Con-**



Confirmation









**Declaration of Con**formity

**Test Certificates** 

Marine / Shipping

other



Type Test Certificates/Test Report



Confirmation

## Further information

Siemens has decided to exit the Russian market (see here).

https://press.siemens.com/global/en/pressrelease/siemens-wind-down-russian-business

Siemens is working on the renewal of the current EAC certificates.

Please contact your local Siemens office on the status of validity of the EAC certification if you intend to import or offer to supply these products to an EAC relevant market (other than the sanctioned EAEU member states Russia or Belarus).

Information on the packaging

https://support.industry.siemens.com/cs/ww/en/view/109813875

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RQ3052-1SM30

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RQ3052-1SM30

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)


https://support.industry.siemens.com/cs/ww/en/ps/3RQ3052-1SM30

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)

http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RQ3052-1SM30&lang=en

**Characteristic: Derating** 

https://support.industry.siemens.com/cs/ww/en/ps/3RQ3052-1SM30/manual



last modified: 6/30/2023 🖸